



•Professional installation recommended.  
 •EasyGlide Track must be anchored every 24" or less, and within 4" of the ends.

•Use 9/64" drill bit to drill holes in track.  
 •Use #48 or 1/16" drill for pilot holes in wood when installing with wood screws.  
 •Use a 3/8" drill bit for plasterboard/drywall when installing toggle bolts.