

## AnoFrame SwivelMount<sup>TM</sup> assembly

## with Various Bases

## Steps 1. For ceiling anchor For scissor anchor



\*Twist scissor clip to loosen, attach to grid, and twist to tighten.









