


# Spider RoPole® Instructions

## Spider RoPole with assembled components




## To install

Assemble poster, sign holders, hook and anchor onto RoPole head (see illustration on front).

Rest heel of RoPole on floor. Loosen telescopic joints and extend pole to the ceiling. Lock the RoPole joints.

**Figure 1**




Line up the wings of the RoPole head under the ceiling grid (Fig. 1). Push up lightly against the grid. Twist the RoPole to the right until the anchor locks.

## To remove

Rest heel of RoPole on floor. Loosen telescopic joints and extend pole to the ceiling. *Firmly* lock the RoPole joints.

**Figure 2**



Line up RoPole head with grid as shown (Fig.2). Push up lightly. With the anchor engaged in the RoPole head, turn the RoPole to the left until the anchor releases.

Lower slowly.

The RoPole® and the OneUp® are registered with the U.S. Patent and Trademark Office. OMNI IN-2000 1/97  
Call with questions: (800) 631-9707  
International: (978) 825-0020

**rose displays**  
The Signware Specialists

35 Congress Street, Salem MA 01970  
Tel# 1-800-631-9707 Fax# 1-800-560-2890  
e-mail: signware@rosedisplays.com