








To insert graphic



To remove graphic



Tilt pole towards you to
release magnetic hold.
Do not pull straight down!



Like all magnets, do not get them too close to watches (or anything with a battery), wallets, computers, pace makers, etc.